

ENVIRONMENTAL PROTECTION

PRODUCTS

Absorbentes



Trivorex® is an absorbent and a neutralizing powder for all types of chemical spills. Unlike "ordinary" absorbers that only aim to capture and limit the spread of the waste, Trivorex® also provides a rapid and effective neutralization of the chemical waste, whether it is oxidizing substances, strong acids or bases such as hydrochloric acid, sulfuric acid and sodium hydroxide (lye). Trivorex has a built-in pH indicator and has no toxicological impact on human tissue and is classified as non-irritant to skin.

Art nr	Description	Scope	
15-5-700	Trivorex® Ca700g	Less chemical waste ex laboratory environment	
15-5-10	Trivorex® Bucket 10kg	Major chemicals spillage where it's important to limit the extent of the spill	
15-0-700	Trivorex® Bucket 700g incl orange holder	Trivorex® incl. holder for Diphoterine rinsing station	
15-0-701	Trivorex® Bucket 700g incl black holder	Trivorex® incl. holder for Hexafluorine rinsing station	



Since slipping accidents are the most common type of accidents in industry, we have an absorbent that is especially effective in spills of oils, paints, polymers, surfactants and flocculation products. Common to these is that they provide a slippery floor and are difficult to absorb. After the use of Polycaptor®, the surface is completely dry compared to other products on the market that leave behind a greasy and slippery surface. In the event of a spill, you never have to doubt whether it is right to use Polycaptor®. Polycaptor® works effectively on all types of liquids. Environmentally friendly.

Art nr	Description	Scope	
20-0-383	Polycaptor® Bas 400g	Varningsstolpe med Polycaptor i. Foten fungerar som en skrapa	
13-5-831	Polycaptor® Hink 4kg (15L)	Större yta som behöver begränsas och saneras	
13-5-832	Polycaptor® Säck 10kg (40L)	Större yta som behöver begränsas och saneras	



Absorbent and neutralizing powder with built-in pH indicator, for all types of acids.

Art nr	Description	Scope	
13-5-802	Acicaptal® Burk 600g	Less waste of acids	
13-5-801	Acicaptal® Hink 9kg	Major spills of acids	

ENVIRONMENTAL PROTECTION PRODUCTS



Absorbent and neutralizing powder with built-in pH indicator, for all kinds of basic (alkaline) chemicals.

Art nr	Description	Scope	
13-5-812	Basicaptal® Can 600g	Less waste of bases/alkaline	
13-5-811	Basicaptal® Bucket 9kg	Major spills of bases/alkaline	

Sanitizing fluid



Safurex® Neutralizes Chemical residues and spills and shows with an indicator when the area is neutralized. This eliminates the risk of corrosion of equipment and chemical damage to personnel. Through the use of Safurex® the amount of waste is reduced when there no longer is a need to rinse with large amounts of water to dilute the chemical. Safurex® is a decontamination fluid against chemicals that should be used routinely, during maintenance or in the event of an accident involving spills and splashes.

Technical advantages of Safurex® :

- ⇒ Can be used on all types of liquid chemicals
- ⇒ Neutralizes corrosive acids and bases through its amphoteric properties
- ⇒ Neutralizes hydrofluoric acid by encapsulation of the fluoride ions so that they become harmless
- ⇒ Changing color to indicate when the equipment is contaminated with an acid or a base. Once the equipment decontaminated it returns to its original color

Not harmful to humans and the environment, not irritating and non-flammable. Can be used on Any Surface

Art nr	Description	Scope	
20-3-750	Safurex® 750ml spray	Smaller areas to be decontaminated	
20-3-5S	Safurex® 5L Decontamination sprayer	Larger areas that need to be decontaminated	
20-3-5	Safurex® 5L Can	Replenishment to decontamination sprayer	
20-3-10	Safurex® 10L Can	Replenishment to decontamination sprayer	